R. L. DRAKE COMPANY

Miamisburg, Ohio

AC-3/L-4 ADAPTOR CABLE

This cable is used to provide AGC and relay contact control to the DRAKE L-4 Linear Amplifier when used in conjunction with a DRAKE TR-3, TR-4 or T-4/T-4X powered with an AC-3 Power Supply. It is not required when an AC-4 is used.



10.3.66